

How to scan between two sets of frequencies.

In the CPS – Optional Settings – VFO Scan

Set your start and end Frequencies

Optional Setting x

Work Mode	Vox	STE	FM	Power Save	Key Function	Other	Digital Fun
Power-on	Alert Tone	Display	GPS/Ranging	VFO Scan	Auto repeater	Record	Volume/Audio

VFO Scan

VFO Scan Type	CO
VFO Scan Start Freq(UHF)	453.00000
VFO Scan End Freq(UHF)	459.00000
VFO Scan Start Freq(VHF)	136.00000
VFO Scan End Freq(VHF)	174.00000

OK Cancel

Go to VFO Mode on the radio.

Push Programming Scan Key to start scan.

(You will need to set a Function Key for Programming Scan)

Short Key P5	Programming Scan
--------------	------------------

Scan Type: Select

TO – 5 sec stop

CO – 2 sec stop

SE – stops scan

You might want to read “[Scanning DMR VFO Frequencies](#)”

To Scan Frequencies outside this range.

Enter a Frequency via the Key Pad

Push Scan Key to start scan.

(You will need to set a Function Key for Scan)



TIPS

Turning the Channel knob **left** will make the scan go **down** the Frequencies

Turning the Channel knob **right** will make the scan go **up** the Frequencies

<http://tiny.cc/AnytoneDMR>