


DMR MODE



1. Simplex = DMR Tier I (TX/RX on both slots at same time)
2. Repeater = DMR Tier II (TX/RX on Slot 1 or Slot 2)
3. Double Slot = Simplex DMR Tier II (TX/RX on Slot 1 or Slot 2)

For Ham Radio DMR Simplex Frequencies, we would use – Simplex = **No1**
[UK Simplex Frequencies Link](#)

For Ham Radio DMR Repeaters, we would use Split Frequencies – Repeater = **No2**

For Ham Radio doing events we would use Double Slot. = **No3**
This lets us have two channels on the same Frequency. Slot 1 and Slot 2

Business users on Simplex Frequencies, you should use – Double Slot = **No3**
This lets us have two channels on the same Frequency. Slot 1 and Slot 2

<http://tiny.cc/AnytoneDMR>